




WESTIN

STRATUS AIR

Ceiling Built-in Unit

Installation, Operation and Maintenance

INTRODUCTION	2
IMPORTANT INFORMATION	2
EXTRACTION PERFORMANCE	2
INSTALLATION	3
SPECIFICATIONS	5
OPERATING INSTRUCTIONS	6
MAINTENANCE	6
ILLUSTRATIONS	7
GUARANTEE	10



Unpacking

Remove all items from the packaging. Retain the packaging.
If items are missing or damaged, please contact Westin for assistance.
The following items are included:

Ceiling Built-in Unit STRATUS AIR Installation, Operating & Maintenance Instructions



1. INTRODUCTION

During the cooking process, there will be heat, vapours and fumes produced. Your *Westin Ceiling Extractor* has been designed to complement your kitchen both in looks and performance in order to create a good environment for creative cooking.

2. IMPORTANT INFORMATION

The exhaust air must not be discharged into a flue which is used for exhausting fumes from appliances supplied with energy other than electricity e.g. oil- or gas-fired central heating boilers, gas-fired water heaters, etc.

Requirements of the relevant authorities concerning the discharge of exhaust air must be complied with.

WARNING.

Proper care must be taken to ensure that the negative pressures caused by high performance extraction systems do not adversely affect the safe operation of certain types of fuel-burning appliances (gas, oil or solid fuel), including those installed in the kitchen and possibly also those installed in other parts of the house.

Where such fuel-burning appliances are installed, adequate ventilation **MUST** be provided in the room of installation, located and sized such that the negative pressure in the room created by the extractor does not exceed 4Pa.

In case of doubt, do not operate the extractor and fuel-burning appliance(s) simultaneously and consult an appropriate (for the fuel type) expert for advice.

ELECTRICAL SAFETY.

This appliance requires an earth connection.

Ensure that the supply voltage corresponds to that marked on the rating label inside the extractor.

The extractor must be isolated from the electrical supply before carrying out any cleaning or maintenance operations.

Pay particular attention to fire risk when frying. To minimise the risk of fire, all instructions relating to cleaning the grease filters and removing grease deposits must be adhered to.

Do not flambé under the extractor.

The clearance between the hob burners and the bottom surface of the extractor must be at least 750mm to prevent overheating of the extractor and its components.

Please also note that a 90° bend in flexible ducting will require 215mm minimum headroom to give a smooth radius with no kinking.

You are advised to install measures designed to reduce the incidence of cold draughts entering the property via any ductwork.

- For extractors with internal or inline motors, this should, at the very least, consist of an external duct termination with integrated non-return flaps (e.g. gravity shutter wall grille/louvre) and/or an inline backdraught shutter.
- For wall-mounted motors, an inline backdraught shutter is recommended.

This extractor has no lights, however there is a light control button on the remote-control console.

So this button may be of use, a switched 230V AC electrical output is provided, operated by the light button. You will find a terminal box, containing Live, Neutral & Earth wires that can be used to power your own auxiliary lights (up to 100W), or ignored according to preference.

3. EXTRACTION PERFORMANCE

As its name suggests, this type of extractor is designed to fit into the ceiling void, with only the underside and outer flange visible when installed.

Because fumes spread out as they rise, a unit larger than the hob area is desirable, although not always possible. The perimeter extraction system is designed to conceal the grease filters and to minimise fume escape. Warm cooking fumes that do escape tend, initially, to accumulate in the highest part of the room, so situating the unit at the highest point is of benefit. It will perform best when it is situated directly over the hob.

The primary influence on the overall performance of the extractor is the design of the ducting which takes the exhaust air from the extractor to the outside. The duct route should be a prime consideration during the initial stages of the kitchen design (Westin do not recommend recirculating air back into the kitchen).

Please note the following:

- Easy access to the duct route during installation is important. Lack of access may require the "blind" fitting of flexible ducting, with increased risk of unseen kinks and impaired efficiency.
- **The extractor is provided with a spigot(s) suitable for connecting 150mm round ducting (or equivalent cross section). Ducting must not be reduced.**
Note: Failure to adequately fit the ducting stated above will void your written Guarantee under the Standard Guarantee conditions.
- The most efficient configuration is to duct straight through an outside wall, so try to position the cooker against an outside wall when designing your kitchen.
- Your extractor can be set to vent to the rear, front, left or right. Use the exhaust position which gives the shortest achievable duct route and least number of bends. Joist positions will often determine what is achievable.
- Rigid 150mm round ducting or an equivalent flat channel system (available from *Westin*) will perform best, with semi-rigid (often referred to as flue liner) being the second-best solution. Flexible ducting is economical but its use should be minimised as it gives the worst performance and should only be used for short duct runs or initial connection (and should be pulled taut to prevent significant losses in extraction efficiency).
- For maximum efficiency, ducting should be kept as short as possible and as straight as possible with a constant cross-sectional area being no less than that recommended by *Westin*. Bends in the duct will also degrade performance so the number of bends in a duct run should be kept to a minimum and be gradual and smooth to prevent turbulence. Avoid kinks in flexible ducting; pull flexible ducting taut over straight runs to ensure that the internal surface is as smooth as possible.

Ceiling Built-in Unit STRATUS AIR

Installation, Operating & Maintenance Instructions



4. INSTALLATION

The extractor is designed for installation within a cut-out in the underside of the kitchen ceiling. Alternatively, it may be installed within a lowered area of ceiling or a soffit panel within your furniture – remember though that it is desirable to install directly into the ceiling (see section 3).

Dimensioned drawings and illustrations to help with your installation can be found on page 7 onwards.

Please note the following.

- The extractor is made up of two main parts*:
 - The “top box”, which houses the exhaust ducting spigot, grease filter, electrical connection points and any internal motor.
 - The “baseplate”, which is essentially the visible parts when installed, comprising hinged filter concealment door panel assembly and outer frame.
- The ducting spigot must be set to the required outlet position prior to installation (Left, Right, Front, Rear or Top).
- The Stratus Air “top box” has 3 possible duct spigot positions. It is easily separated from the baseplate and can be rotated through 180 degrees in order to achieve all 5 possible outlet directions. It is secured via screws accessible only when the filter concealment door panel is in the open position.
- The extractor fixing holes are located behind the door panel. We recommend pan-head or flanged screws are used to secure the extractor, rather than countersunk. Screw heads will be visible only when the door is open.
- **If your extractor is a recirculating model** (optional extra and not the standard configuration) then adequate provision must be made for exhausted air to return to the kitchen, such as by ducting to a vent in the kitchen ceiling (located so as to minimise uncomfortable draughts onto occupants). Failure to do so may cause the unit to overheat and fail, and will invalidate your warranty.
- This extractor has no lights, however there is a light control button on the remote-control console.

So this button may be of use, a switched 230V AC electrical output, operated by the light button is provided. You will find a terminal box, containing Live, Neutral & Earth wires, that can be used to power your own auxiliary lights (up to 100W) or ignored according to preference.

4.1. Opening the filter concealment door panel.

The panel is held shut with magnetic catches. Open the panel by grasping it close to the corners on the catch side (the long edge opposite the hinges) and pulling to release the panel from the magnets. Take care not to let the panel fall open freely, it should be supported and moved carefully into the open position.

4.2. Setting the Duct Spigot Position.

Your extractor ducting spigot can be set to vent to the Left (factory default), Right, Front, Rear or Top.

The front of the unit, when installed, is the side with the magnetic catches.

Note: If you wish to vent upwards and space is restricted, then you may find your installation easier if you use a side outlet position and put a bend in your ducting.

The “top box” exhaust spigot assembly refers to the removable 150mm ducting spigot plate, which in the case of Internal blower models has the motor attached to it.

- As described earlier, the Stratus Air “top box” has 3 possible duct spigot positions, with the remainder being achieved by rotating the top box through 180 degrees.

To change the exhaust spigot position of the “top box” proceed as follows:

- Suspend the extractor on its back *such that the “top box” is clear of the ground. Tip. This can be achieved by placing the product across the top of the open box it came in so that the “top box” hangs down into the box.*
- Open the filter concealment panel and remove the filter(s).
- Each exhaust position has 4 captive nuts into which can be bolted either the exhaust spigot assembly or a blanking plate.

Bolt the exhaust spigot assembly into the required location by swapping it with a blanking plate as necessary.

Note: For internal blower models, where space within the top box is limited, only the screws nearest to the filter opening need to be fully removed. The screws farthest away need only to be backed off as the plate has slots for easier removal/replacement of the motor.

To rotate the “top box” proceed as follows:

- Suspend the extractor on its back *such that the “top box” is clear of the ground. Tip. This can be achieved by placing the product across the top of the open box it came in so that the “top box” hangs down into the box.*
- Open the filter concealment door panel to reveal the fixing screws securing the “top box” to the “baseplate” and remove the screws.
- Carefully lift the “top box” out of the “baseplate” opening, rotate it to face the required direction and carefully refit it in its new position, taking care not to trap any wires. Secure it with the screws previously removed.

Important.
The “top box” needs to be angled during removal and refitting to allow the duct spigot, electrical connection points and cables to clear the opening in the “baseplate”.

4.3. Revealing the Fixing Holes.

The extractor is secured through 4 fixing holes located close to each corner of the baseplate (see diagrams on Page 7 Onwards for detail).

The fixing holes are only accessible with the door panel open.

4.4. Prepare Opening

Prepare an opening in the ceiling into which the unit will be fitted (see table below). Refer to the drawings on Page 7 & 8 for detailed opening design and clearance height information.

Unit Size (mm) (Width x Depth)	Cut-out Size (mm) (Width x Depth)
880 x 420	860 x 400
1180 x 420	1160 x 400

Reinforce the opening as necessary and make suitable provisions for the screws that will hold the unit in place.

Tip: Because much of the baseplate only intrudes into the ceiling by 30mm (see diagrams on Page 7 Onwards), providing the joist direction runs such that the top box can be

Ceiling Built-in Unit STRATUS AIR

Installation, Operating & Maintenance Instructions



accommodated, alterations to joists and any boxing down can be kept to a minimum, or avoided altogether if the ceiling thickness is sufficient or ceiling can be lowered slightly.

4.5. Ducting

Install ducting taking note of the advice given in section 2 & 3.

We recommend using semi-rigid round ducting for this extractor – the initial connection to the extractor spigot must be in semi-rigid (or flexible duct) to allow the unit (or top box if fitting separately) to be installed with the duct connected.

Run the ducting such that there is enough to easily reach just beyond the centre point of the extractor, thus allowing for a short length to be pulled through the opening for later connection to the top box spigot. Try to avoid tight bends immediately adjacent to where the top box will be, as this will make pushing the unit/top box into position more difficult.

When terminating ducting on an outside wall, a suitable weather louvre should be used. Ducting components and complete kits are available from *Westin* for most installations.

If you need to use expanding foam, make sure that any soft flexible ducting is supported internally to prevent it crushing, or use semi-rigid/rigid ducting where foam is used.

For roof or chimney duct terminations, please contact *Westin* or seek alternative specialist advice.

If you are fitting a wall-mounted external motor with semi-rigid or flexible ducting, then you must leave a short length (approx. 200mm) of expanded (stretched out) ducting proud of the wall to facilitate connection to the motor spigot before pushing both into position flush with the wall.

Standard external motors come with a cable assembly that must pass through the wall and run back to the extractor – usually this passes alongside the ducting so it is recommended to oversize your cut-out by at least 25mm to allow for this and easy installation of the duct.

4.6. Remote External Wall and Inline Motors

If your extractor has been purchased to operate with a standard inline or external remote motor (SEM), then you will find a black plastic box outside the extractor (on flying leads) containing electrical terminals for connection to the remote motor cable assembly. This box is referred to as the remote motor terminal box.

Run the remote motor cable such that sufficient hangs down through the ceiling opening prepared for the extractor to allow for easy connection to the remote motor terminal box.

Each terminal inside the remote motor terminal box has one side connected to a coloured wire (leading back to the hood control system). The remote motor cable also has coloured wires and these are connected to the empty terminals such that corresponding colours are opposite and connect to each other; i.e. red connects to red, blue to blue, and so on...

Not all terminals will be used as each remote motor type is configured differently.

No separate power supply is required for the external motor.

An electrician (or Part P registered electrical installer) should undertake any work associated with the electrical installation of SEM remote motors.

Please refer to the *REMOTE MOTOR ILLUSTRATIONS* on page 9 for more information.

If you need to extend the remote motor cable, then additional cable can be purchased from *Westin*. Alternatively, it can be extended using 7 core x 0.5mm flex. It is vital to ensure that any

new cable is inserted such that the core colour integrity is maintained; i.e. a core that started as red must terminate as red, blue as blue, purple as purple, and so on.

Any remote motor should be installed in accordance with the installation instructions that accompany it. It must be installed in an easily accessible location for future maintenance. *Westin* are not responsible for providing the means of access (e.g. scaffolding or any alterations to the building and/or furniture necessary to make access possible) in the event of any maintenance requirement.

4.7. Electrical Installation

**ELECTRICAL HAZARD.
DISCONNECT ELECTRICAL SUPPLY
BEFORE PROCEEDING FURTHER**

The extractor is a stationary appliance supplied with an electrical supply flex and moulded 3 pin UK plug (3A) for connection to the electrical supply.

The appliance must be fed from a 230Vac single phase electrical supply. You may wish to terminate the electrical supply using a standard mains electrical socket positioned close to the extractors intended location.

Alternatively, you may terminate the electrical supply from a switched-fused spur. The spur should be located adjacent to the hood/cooker so that the supply can be disconnected from the hood using the switch. The means of disconnection from the supply must have a minimum contact separation of 3mm in all poles. A competent Part P registered electrical technician must perform the electrical installation.

The mains supply is connected as follows:

INCOMING SUPPLY CORD CONNECTIONS	
Core	Core Colour
Live	Brown
Neutral	Blue
Protective Earth	Green/Yellow

Make sure the switched - fused spur supplying the extractor is in the 'off' position before connecting the appliance to the electrical supply.

Because this extractor has no lights but the remote controller retains a light control button, we provide a switched 230V AC electrical output that can be used to power your own auxiliary lights (up to 100W) or ignored according to preference. You will find a small terminal box containing Live, Neutral & Earth wires to power lights, should you wish to use it.

4.8. Fixing the Extractor in Position

Please note the following prior to commencing fixing the extractor in position:

- You will need at least 2 people to fit this extractor; to lift, hold and fix the unit in position:
- A working platform or scaffold should be used so that the ceiling opening can be reached and the unit fixed without the use of ladders.
- Screws for fixing the extractor into position are not provided. You must use suitable fixings capable of supporting 30kg.

If you are screwing into timber, then you should use screws no smaller than 5mm (No 10) with a head diameter of 10mm or more and ensure that at least 35mm of thread is screwed

Ceiling Built-in Unit STRATUS AIR Installation, Operating & Maintenance Instructions



into the timber and that the timber will not split when the screws are inserted.

- The unit will need supporting close to the opening when attaching the ducting and making electrical connections – do not be tempted to install excessive ducting as this will impair performance.

As described earlier, a length of semi-rigid ducting protruding a short distance through the centre of the ceiling opening is sufficient for the final connection to the extractor spigot. This will allow the unit to be fixed into position with the duct connected and prevents excessive lengths of flexible ducting being pushed into the opening (and the resultant losses in efficiency which that would cause (see section 3)).

Note that it is possible to separate and withdraw the spigot assembly back into the top box (working through the filter opening). Whilst this should not be necessary, it is worth noting as it may help you overcome difficulties, particularly if your ducting has been cut too short, as you will be able to attach it to the spigot from inside the extractor.

You must consider and allow for the future removal of the extractor and any remote motor when planning and undertaking your installation in case future access for servicing is required.

If you have not already done so, set the top box to duct out in the required direction, as described in section 4.2, and reveal the corner fixing holes, as described in section 4.3.

**ELECTRICAL HAZARD.
DISCONNECT ELECTRICAL SUPPLY
BEFORE PROCEEDING FURTHER**

If you wish to power lights of your own with this extractor, then these should be wired into the switched 230V AC output terminals provided now. Note: Should you wish to, auxiliary mains powered lighting of up to 100W can be powered by this extractor. Terminals can be found within the small lighting terminal box (see diagrams on Page 7 Onwards). A qualified electrical technician must be used to connect any auxiliary lighting to this appliance.

If using a remote motor, connect it now, as described in 4.6. The illustrations on page 9 will help you.

Support the extractor just below the prepared cut-out so that the spigot and electrical connections are accessible.

Make sure that the electrical supply to the electrical supply spur is isolated (switched off) and connect the electrical supply cord of the extractor to the spur.

Attach the ducting to the spigot using suitable clamps or straps. We do not recommend using duct tape as the only means of fixing ductwork.

Now push the extractor (and any wires and terminal boxes) up into the cut-out, taking care not to crush or introduce excessive bends/kinks in the ducting and making sure that no wires are trapped or damaged in the process.

Note: If the duct or any wires are trapped, then you must lower the extractor and make corrections to the cut-out area as necessary, before fixing the appliance in position.

Secure the extractor in place using suitable fixings (not supplied) through the fixing hole in each corner of the baseplate.


Now test the function of the unit as described in the operating instructions (Section 6).

If the unit does not function correctly then isolate the electrical supply and check all the electrical connections before contacting Westin.

If you experience any difficulties, please call Westin for advice.

4.9. Removing the Motor Transport Ties (If Fitted) (see fig.2)

Note: Transport Ties are only used on smaller appliances to protect the motor during unpalletised transit.



5. SPECIFICATIONS

All Models	
Supply voltage:	230V ~ 50Hz
Recommended fuse size for electrical supply:	3A
Extractor Duct spigot diameter:	150mm
Stratus Air with Internal Motor	
Motor airflow in free air:	800 m ³ /hr
Blower power input:	275W
Total power:	276W
Stratus Air with SEM1 EL Inline Motor	
Motor airflow in free air:	800 m ³ /hr
Motor power input:	275W
Total power:	276W
Stratus Air with SEM2 EL External Wall Motor	
Motor airflow in free air:	900 m ³ /hr
Motor power input:	200W
Total power:	201W
Stratus Air with SEM7 EL External Wall Motor	
SEM7 airflow, in free air: 200mm Dia Duct	1,700 m ³ /hr
SEM7 airflow, in free air: 150mm Dia Duct	1,500 m ³ /hr
Motor power input:	490W
Total power:	491W
<i>Note: The motor has a 200mm diameter spigot and is supplied with a reducer for connection to 150mm ducting.</i>	
Stratus Air with SEM8 EL Inline Motor	
SEM8 airflow, in free air: 200mm Dia Duct	1,300 m ³ /hr
SEM8 airflow, in free air: 150mm Dia Duct	1,100 m ³ /hr
Motor power input:	250W
Total power:	251W
<i>Note: The motor has a 200mm diameter spigot and is supplied with a reducer for connection to 150mm ducting.</i>	
<i>Important Note: Any optional auxiliary lighting powered by this appliance is not included in the stated power figures shown above.</i>	
Maximum wattage of auxiliary lights (not supplied or you may power with this appliance):	100W

Ceiling Built-in Unit STRATUS AIR

Installation, Operating & Maintenance Instructions



6. OPERATING INSTRUCTIONS

Switch on the power at the fused spur.

- The unit is operated by radio remote control.
- Should the extractor fail to respond to commands from the remote-control console, then please check that the power is on and the internal appliance reset switch is in the 'On' position (factory default). The reset switch is a latching red push-switch located in the chamber behind the grease filter(s).

Press the switch fully in to change between 'on' and 'off' modes. If you are unsure as to the position of the switch, you can repeatedly press the light switch on the remote control console during the boot sequence (which lasts about 15 seconds) to register the remote to the appliance. - When registered, if the switch is in the 'on' position, you should hear the lighting relay inside the hood click quietly, or if you have lights connected, they will illuminate.

- Should your remote-control stop working, you should install a new battery before seeking further assistance.
- If you experience interference problems or the remote appears to be faulty from new, then a different radio transmission code may be required.
- Refer to the instruction leaflet included with the radio remote control console regarding battery replacement and transmission code changes before seeking assistance.

7. MAINTENANCE

Regular maintenance is essential to ensure good performance and long-life.

CAUTION.

To minimise the risk of fire, all instructions relating to cleaning the grease filters and removing grease deposits must be adhered to.

To maintain the immaculate appearance of the extractor, and to minimise fire risk, ensure that grease deposits on the extractor surfaces are kept to a minimum by regular cleaning.

To clean the stainless-steel surfaces of the extractor, use a soft cloth and a suitable cleaning agent, such as a specially produced stainless-steel cleaner or washing up detergent and warm water.

Painted surfaces should be cleaned using a soft cloth, detergent and warm water.

Glass surfaces should be cleaned with a suitable glass cleaning agent.

- **Do not use abrasive cleaning materials or products.**
- **Do not use bleach-based cleaning materials or products.**

Clean the grease filters in a dishwasher or by hand-washing in hot water and detergent every 2 months - sooner if the extractor is used extensively and filters become grease laden.

- Whilst you can expect years of service from mesh grease filters, they are considered a consumable item and may deteriorate over time and need replacement, particularly when cleaned in a dishwasher. For dishwasher users adhering to a 2 monthly cleaning interval, we recommend grease filter replacement every 5 years to maintain optimum performance, even if they show no visible signs of deterioration. For all users, filters should be replaced whenever they exhibit signs of physical wear.

Accessing the filter(s) and baseplate


The panel is held shut with magnetic catches.

Open the panel by grasping it close to the corners on the catch side (usually the long edge opposite the hinges) and pulling to release the panel from the magnets. Take care not to let the panel fall open freely, it should be supported and lowered carefully into the open position.


No lights are supplied with this extractor.

Main Reset Switch

The Reset Switch is a red rectangular switch located inside the extractor. The Switch can be accessed by opening the Door and removing the Filter(s). Press the Reset Switch to unlatch 'out'. Press the Reset Switch again to relatch 'in'. The Switch must be in the latched 'in' position in order for the extractor to operate.



Remote Control Functions



The extractor controller will automatically switch off the appliance if there has been no operator action for 4 hours.

** The automatic speed reduction feature is required to comply with EU Ecodesign and Energy Labelling legislation. Our highest performance SEM remote motors require speeds to automatically reduce to speed 2.*



W S Westin Ltd
Phoenix Mills, Leeds Road, Huddersfield, HD1 6NG, UK
Tel: 01484 421585 Fax: 01484 432420 Email: sales@westin.co.uk
www.westin.co.uk

Ceiling Built-in Unit STRATUS AIR Installation, Operating & Maintenance Instructions



STRATUS AIR 3D General Arrangement Drawing Internal Motor Version

Cutout Details: Width 860/1160 x Depth 400
Spigot Size: \varnothing 150





This extractor has no lights, however there is a light control button on the remote control console.

We therefore provide a switched 230Vac electrical output (switched on/off when the light button is pressed) and a terminal box (containing Live, Neutral & Earth wires) that can be used to power your own auxiliary lights (up to 100W) or ignored according to preference.

STRATUS AIR 3D General Arrangement Drawing Remote Motor SEM EL Version


Cutout Details: Width 860/1160 x Depth 400
Spigot Size: \varnothing 150



This extractor has no lights, however there is a light control button on the remote control console.

We therefore provide a switched 230Vac electrical output (switched on/off when the light button is pressed) and a terminal box (containing Live, Neutral & Earth wires) that can be used to power your own auxiliary lights (up to 100W) or ignored according to preference.

Ceiling Built-in Unit STRATUS AIR Installation, Operating & Maintenance Instructions



Set support surface 35mm up from opening so the extractor can be pulled up flat against the ceiling by your fixing screws.

Do not overtighten screws. The extractor hangs within the aperture created.

Ceiling Built-in Unit STRATUS AIR Installation, Operating & Maintenance Instructions



8. 7. SEM EL REMOTE MOTOR ILLUSTRATIONS

The wiring illustrations below apply to SEM EL Motors only.

The below diagram shows a typical SEM EL wiring schematic. the appliance is supplied with an external terminal box that requires connecting to the external motor.

In order to access the electrical terminals, remove the fixing screws from the external terminal box lid. Refer to fig. 2 & 3 for details of how to wire the SEM 1/2 or SEM 7/8 correctly.




Fig. 1 Typical System

Fig. 2 Terminal Colour Positions






Fig. 3 SEM 1 / SEM 2
Electrical Connections



Remote Motor Cable Assembly
Orange/Yellow link wire is included

Fig. 4 SEM 7 / SEM 8
Electrical Connections



Remote Motor Cable Assembly
(Orange/Purple link wire is included)

Note:
CHECK: COLOUR SEQUENCE MAY VARY
Link terminals determine intensive speed run times, which are motor type dependent.
Aux terminal powers auxiliary PCB in some motors.

**Ceiling Built-in Unit
STRATUS AIR
Installation, Operating & Maintenance Instructions**



STANDARD GUARANTEE CONDITIONS

Westin Ltd undertakes that if within 24 months of the date of delivery this product or any part thereof is proved to be defective by reason only of the faulty workmanship or materials, the company will, at our option, repair or replace the same FREE OF ANY CHARGE for labour, materials or carriage on condition that:

1. The product has been correctly installed and used only on the electrical supply stated on the rating plate.
2. The product has been used for normal domestic purpose only, and in accordance with the manufacturer's operating and maintenance instructions.
3. The product has not been serviced, maintained, repaired, taken apart or tampered with by any person not authorised by us.

EXCLUSIONS

This Guarantee does not cover:

- Damage or calls resulting from incorrect installation, transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right appliances improperly installed or calls to appliances outside the United Kingdom.
- Normal wear and tear.
- Products deemed to be in use within a commercial environment.
- Grease filter mesh.
- Bulbs and LEDs.
- Consumables.
- Damage caused to the body by usage of detergent sprayer or other contaminants.
- Damage or corrosion of the LED parts, glass parts and stainless-steel parts.
- Damage caused by foreign objects or accident.
- Any products taken apart or serviced by unauthorised individuals or service engineers or replaced with other manufacturer's components.
- Product not installed with the correct size ducting as stated in the manual.

This Guarantee is in addition to your statutory and legal rights.

Please see our website www.westin.co.uk for details of our Conditions of Sale and to register your guarantee.